

MOD 102 Chassis Hole Modification for Mounting Hammond Mfg. 369EX

Since the 369EX world power transformer has larger footprint mounting dimensions than the 269EX, we recommend drilling the two existing TR1 outside #6 mounting holes larger to fit #10 screws (0.194" diam.) and drilling two new #10 holes to mount the 369EX. First, drill the outside #6 holes larger, then place the feet of the 369EX over those two holes while using a center punch to mark the center of the other two mounting holes. Now, drill out the two new holes to fit #10 screws where you had marked them.

