


Drawing 1

REAR




FRONT


SIDE

SIDE

Drawing 2






Drawing 3




Drawing 4


FRONT (INSIDE VIEW)




BASS




TREBLE



VOLUME




INPUT




Mount the power switch with solder lugs towards the chassis top.

CHASSIS TOP

REAR (INSIDE VIEW)




OUTPUT TO SPEAKER(S)



FUSE HOLDER

Power Cord Hole:
Leave open for now





CHASSIS TOP







Drawing 5

FRONT







Drawing 6



Drawing 7



Drawing 8



Drawing 9